



# How to easily fix a Xbox 360 drive that wont open.

Written By: Matt Weatherly



## TOOLS:

Tweezers (1)  
Paper Clip (1)  
Paper Towels (1)

### Step 1 — How to easily fix a Xbox 360 drive that wont open.



- First we need to take off the face plate.

### Step 2



- Use a paper clip or a long pick tool to manually open DVD Drive.

### Step 3



- Use [tweezers](#) to take a rubber belt of 2 pulleys in between the hole in the DVD Tray.


### Step 4



- Use a damp paper towel to thoroughly clean the rubber belt.



## Step 5



- Use the tweezers to put the rubber belt back on the 2 pulleys we took them off of.
- I have found it is easier to start with the big pulley first then once around the big pulley get the belt around the small belt.

## Step 6



- Close the DVD Drive and put the face plate back on.
- Plug the system in and test to see if the drive works.

---

These steps have helped me fix 2 original Xbox systems and 3 Xbox 360 systems. I hope it helps yall. If you need any clarification on any of the steps please message me.

