



# ASUS ROG G750JW-RS72-CB Display Assembly Replacement

If your screen is broken, this guide will show you how to replace it.

Written By: Sully Chen



---

# INTRODUCTION


In this guide, we will replace the screen of the Asus ROG G750JW-RS72-CB.



## TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Battery



- **i** Make sure you completely power down the computer before beginning this process.
- With your finger, push this slide to the right. The battery should pop out of place.

## Step 2



- Pull the battery out of its place gently.



## Step 3 — Hard Drive




- Lift up the flap using a plastic opening tool.
- Hold the flap back with your finger.

## Step 4



- Unscrew the 5.2mm screw underneath the flap.

## Step 5



- Once the screw is out, pull on the plastic tab to pull off the plastic cover.

## Step 6



- Unscrew the 5.2mm screws holding the hard drive in place.
- Gently pull the rubber hard drive mount to the side.
- Pull the drive out.



## Step 7 — Display Assembly





- Remove the 8.5mm screws holding the bottom half of the laptop together.

## Step 8



- Take a metal separator and gently pry open the back end of the laptop halves.

## Step 9



- Remove the connector connecting the screen and the motherboard

## Step 10



- Unscrew the 6.8mm screws holding the hinges of the screen to the bottom half of the computer.
- Detach the screen from the hinges of the laptop.

⚠ Be careful not to damage the connecting wires when detaching the screen.




## Step 11



- Use a metal separator to carefully separate the bottom half of the laptop.

## Step 12



- Gently unplug the cables connecting the screen to the motherboard.
- The display assembly can now be freely separated.

To reassemble your device, follow these instructions in reverse order.