



Alienware M15x Battery Replacement

This guide will explain how to remove the battery.

Written By: Drew Austin



INTRODUCTION

This guide will explain how to remove the battery from an Alienware M15x gaming laptop.



TOOLS:

- [Fingers](#) (1)
-

Step 1 — Battery



- Remove the battery by sliding the latch to the left and pulling the battery up.

To reassemble your device, follow these instructions in reverse order.