



KitchenAid KSM150PSEER Bowl Screw Cap Replacement

Replace the bowl screw cap on KitchenAid KitchenAid KSM150PSEER stand mixer.

Written By: Luke Leonard



INTRODUCTION

Removing the bowl screw cap is easy and doesn't take long. If the bowl doesn't stay in properly you might want to replace this part.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Bowl Screw Cap



- Using a #2 Phillips screwdriver, remove the three 13mm screws holding the bowl screw cap on by rotating them counterclockwise.

Step 2



- Remove the bowl screw cap by grabbing the side and lifting up on it.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 06:26:41 AM (MST).

