



Olympus OM-D E-M10 Mark II Lens Replacement

Replace your camera lens to get a different perspective in your shots.

Written By: Channing Pezet



INTRODUCTION

This is a comprehensive guide on how to remove the camera lens from the body in order to clean it or to put a different lens on the camera. If you are taking long range pictures it may be beneficial to put a new lens on the camera in order to increase magnification.

Step 1 — Lens



- Press the black button located to the right of the camera lens when facing the front of the camera.

Step 2



- Grasp the innermost ring on the lens, closest to the camera body, which can be located by the small red dot. This is the only ring that should not turn, unless the button specified in the previous step is held down.

Step 3



- While holding down the button specified in step 1, begin turning the inner most ring, specified in step 2, counterclockwise until the camera lens becomes free from the camera body.

Step 4



- Once the lens is free from the camera body, pull the lens completely away from the body to make sure the lens is truly free.

To reassemble your device, follow these instructions in reverse order.