



Xbox 360 Wireless Speed Wheel Battery Replacement

When the controller is not powering on, a...

Written By: lauren paganella



INTRODUCTION

When the controller is not powering on, a battery replacement could resolve the issue. Plus, taking out the batteries is the first thing you should do when you try to do any repairs on the Wireless Speed Wheel. Safety first!

PARTS:

[AA Battery](#) (2)

Step 1 — Battery



- Turn the controller on its backside and push the "eject" button to discharge the battery compartment door on the bottom of the controller.
 - Pull the two AA batteries out.
-

To reassemble your device, follow these instructions in reverse order.