



# Lenovo X200 Battery Replacement

This guide will tell you how to replace a battery in a Lenovo Thinkpad X200. Before starting the repair, make sure that it is a X200.

Written By: Legendary Ocelot





## PARTS:

- [Thinkpad X200 Battery](#) (1)
-

## Step 1 — Battery



- Flip the Laptop over. It should look similar to this.

## Step 2 — Battery Removal



- Push the switch into the unlock position. Pull the battery out.

### Step 3 — Put new battery in.



- Position the new battery in the same manner as the old battery (with the connectors and lock/unlock switch facing inwards towards the computer). Push the battery in.