



HP Elitebook 2740p Battery Replacement

In this guide we will be replacing the battery of the HP Elitebook 2740p.

Written By: Andrew Furze



INTRODUCTION

If your battery is not lasting as long as you would like or it is not holding charge it may be time to replace it. This guide will go through how to replace the battery for a HP Elitebook 2740p.

TOOLS:

- [Fingers](#) (1)
-

Step 1 — Battery



- Slide the lock tab to the right.

Step 2



- Lift and remove the battery from the battery compartment.

To reassemble your device, follow these instructions in reverse order.