



Toshiba TECRA R940 Battery Replacement

In the guide you will learn how to remove and replace the battery pack on the Toshiba TECRA R940-S9421.

Written By: Jack Dutton



INTRODUCTION

Removing and replacing the battery is a possible remedy to battery charging problems, or a black screen despite the computer receiving power.

This is also the first step in opening the back panel of the computer.

Step 1 — Battery



- Slide lock 1, located on the right side, to the unlocked position.

Step 2



- While holding lock 2 (left side) in the unlocked position, pull out the battery pack.

☑ It is not necessary to hold open lock 2 for re-installation.

To reassemble your device, follow these instructions in reverse order.