



Written By: Charlie Castorena



Page 1 of 4

INTRODUCTION


Before being able to do anything inside your LG G Pad, you will need to remove the back panel. Follow this guide to do so.




TOOLS:

- [Spudger](#) (1)
-

A close-up photograph showing a person's hands using a metal prying tool to remove the back cover of a black smartphone. The phone is held steady by one hand, while the other hand uses the tool to lift the cover at the top edge. The Verizon logo is visible on the back of the phone.

-  Be gentle when popping the panel off.

-  If the panel does not budge, be aware that there is adhesive on the back of the battery holding the back shut. Make sure to just move around the perimeter of the back panel until the panel is able to lift forward.

This document was generated on 2020-11-28 07:04:33 AM (MST).

