



LG Stylo 3 Plus Back Cover Replacement

Use this guide to remove or replace the back cover of a LG Stylo 3 Plus.

Written By: Patricia Pires Dias



INTRODUCTION

Back covers are extremely important since they help protect the battery that powers the phone and also keeps the rear camera of the device safe. If the cover for your device is broken, dented, or scratched, follow this guide to remove and replace the cover.

TOOLS:

- [iFixit Opening Tools](#) (1)

Step 1 — Back Cover



- ⓘ Power off the phone before beginning disassembly.
- Place the phone face down.
- Insert a fingernail or a plastic opening tool into the gap on the side of the phone.
- Carefully slide your finger or the tool throughout the edge of the phone to ease the back case off.

To reassemble your device, follow these instructions in reverse order.