



Samsung Gear VR With Controller USB Connector Replacement

How to replacing the USB connector for the Samsung Gear VR headset.

Written By: Nick Alan Maley



INTRODUCTION

If your phone doesn't have a compatible USB port or if the USB connector breaks, use this guide to swap the connector out for a new one. The Samsung Gear VR can hold a USB Type-C or Micro USB. This guide requires no tools.

Step 1 — USB Connector



- Push the switch on the right-hand side of the device to separate the cover from the main body.
- Pull the cover away from the main device.

Step 2



- Slide the gray switch to the right to unlock the USB connector.
- Lift the connector perpendicular to the device.
- Slide off the USB connector gently with your fingers.

To reassemble your device, follow these instructions in reverse order.