



Ring Spotlight Cam Battery Replacement

This guide will help you replace the batteries in your Ring Spotlight Camera.

Written By: Smoo Rena



INTRODUCTION

This guide will provide step-by-step instructions on how to replace the batteries in your Ring Spotlight Camera.

The process of changing the batteries in your Ring camera can be broken down into three simple steps. This guide includes the steps along with images to demonstrate the steps, making it easy as 1-2-3 to change the batteries in your Ring camera!

Step 1 — Battery



- Turn Ring Spotlight Cam to the back side and flip upside down

Step 2



- Press down on the top button and open upward

Step 3



- Open Spotlight Cam to remove batteries.

To reassemble your device, follow these instructions in reverse order.