



BLU Studio G Battery Replacement

This will guide you through replacing a faulty battery.

Written By: Christian Perez



INTRODUCTION

Over time, batteries lose their ability to hold a charge. If your BLU Studio G is losing charge quickly or won't hold a charge at all, use this guide to replace its old battery with a fresh one.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Battery



- To remove the back cover, locate the safety indented notch on the bottom left corner as the screen is facing down.
- Using your finger (or spudger), prop upwards to detach the back cover properly from the rest of the device.
- Set back cover aside.

Step 2



- Locate the notch at the bottom of the battery for safe removal.
- Carefully lift battery from the notch making sure not to puncture the battery rubber casting.
- Set battery aside and insert new one .

To reassemble your device, follow these instructions in reverse order.