



Samsung Galaxy S III microSD Card Replacement

Internal prereq if removal of microSD card is necessary.

Written By: Walter Galan



INTRODUCTION

Internal prereq if removal of microSD card is necessary.

Step 1 — microSD Card



- Using your fingernail, push the microSD card slightly deeper into its slot, until you hear a click.
 - After the click, release the card and it will pop out of its slot.
- For reassembly, push the microSD card into the slot until it clicks in place.

Step 2



- Use your thumb to slide the microSD card out of the slot.
- Remove the microSD card from the phone.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 02:47:31 AM (MST).

