



Palm Treo 650 Battery and Stylus Replacement

This guide will show how to separate the...

Written By: cgood



INTRODUCTION

This guide will show how to separate the battery from the Palm Treo 650.

Step 1 — Battery and Stylus



- Position the phone so the screen faces down.
- Remove the stylus found on the back of the phone.

Step 2



- Hold the button in the middle of the phone's back to remove the battery cover.
- Slide the cover down to remove it, and set the cover aside.

Step 3



- Lift the edge of the battery, separating contact points, and pull out as pictured.

To reassemble your device, follow these instructions in reverse order.