Lenovo YOGA 730-15IKB Battery Replacement

Follow this guide to replace or remove the...

Written By: Mathew Shaham

INTRODUCTION

Follow this guide to replace or remove the battery in your Lenovo YOGA 730-15IKB. The battery powers the computer when the charger is not plugged in. It is a wise idea to unplug the battery before touching any component inside the computer to avoid hurting the laptop or yourself.

If your computer is running out of battery quickly or will not power on when it is not plugged in, you might need to replace your battery. See the troubleshooting page for more advice.

🔧 **TOOLS:**

T5 Torx Screwdriver (1)
iFixit Opening Tool (1)
Phillips #1 Screwdriver (1)

⚙ **PARTS:**

Lenovo Yoga 730 (15") Replacement Battery (1)

Step 1 — Bottom Cover

⚠ Turn off the computer and unplug the charger before going any further.

- Flip the laptop over so you can see the underside.

- Remove the ten 7mm T5 Torx screws.

Step 2

- Pry up the bottom cover with an opening tool.
 - Start at the front edge of the cover and make your way along the sides.

Step 3

- Pull the bottom cover up and away from the back hinges.

Step 4 — Battery

- Disconnect the battery from the motherboard by gently pulling the battery cable using your fingers or a pair of [tweezers](#).
 ⚠ Pull parallel to the battery, not straight up.

  ⓘ Unplug the cable gently as the eight wires on the connector are very small and delicate.

Step 5

- Remove the four 4mm Phillips #1 screws securing the battery.

Step 6

- Lift the battery up and out of the chassis.

⚠️ Handle the battery carefully. Touching the terminal may cause electric shock. Puncturing the battery may cause it to catch fire.

To reassemble your device, follow these instructions in reverse order.

For optimal performance, after completing this guide, calibrate your newly installed battery.

Take your e-waste to an R2 or e-Stewards certified recycler.

Repair didn't go as planned? Try some basic troubleshooting, or ask our Answers community for help.