



NES Housing Removal

Nintendo Entertainment System (NES) Upper Housing Removal

Written By: Bruno



INTRODUCTION

To get inside the console, both housing parts need to be taken apart.



TOOLS:

- [Kreuzschlitzschraubendreher PH 2](#) (1)
-

Step 1 — Removing housing



- Remove the six 13.50mm PH2 screws from the base plate.
 - ⓘ The screws are countersunk 40mm into the base plate.
- Now take off the upper part of the housing.

To reassemble your device, follow these instructions in reverse order.