



Samsung NaviBot SR8855 disassembly

How to easily disassemble your NaviBot vacuum cleaner.

Written By: martinuk



INTRODUCTION

How to easily disassemble your NaviBot vacuum cleaner, allowing you to clean it from time to time, or to replace a defective part (in my case, the bag presence switch: Error C08, cost 3 Euros).

TOOLS:

- [Kreuzschlitzschraubendreher PH 2](#) (1)
-

Step 1 — Samsung NaviBot SR8855 disassembly



- Remove the dust basket.

Step 2



- Move the switch to "0".
- Unscrew the battery cover.

Step 3



- Disconnect the battery and remove it.

Step 4



- Remove the 2 screws and 2 plastic pieces.

Step 5



- Withdraw the front guard.
- Disconnect the connector.

Step 6



- Remove the guards on each side.

Step 7



- Remove the 2 screws and the cover on each side.

Step 8



- Remove the 2 screws.

Step 9



- Slide the top upwards (watch out for 4 clips).

Step 10



- Remove the 6 screws.

Step 11



- Take off the top cover, and there you have it - your NaviBot is dismantled!

To reassemble your device, follow these instructions in reverse order.