



# Palm IIIx Front Button Cluster Replacement

A guide to replace a damaged, lost, or broken...

Written By: David Haskell



# INTRODUCTION

A guide to replace a damaged, lost, or broken button cluster.



## TOOLS:

Phillips #00 Screwdriver (1)



## PARTS:

Palm IIIx Push Button (1)

Palm IIIx Button Cluster (1)

## Step 1 — Battery



- Place the Palm IIIx face down on a flat surface.

## Step 2



- Push down and lift up the battery cover to remove it.

## Step 3



- Remove the old batteries one at a time.



## Step 4 — Front Button Cluster



- Using a Phillips #00 screwdriver, remove the four screws that hold the back cover in place.

## Step 5



- Hold the device on its side, positioning your hands as shown.
- Remove the back cover by pushing in with your thumbs and pulling outward with the rest of your fingers

## Step 6



- Hold the screen and front cover in a vertical position, facing the screen inward, as shown.
- Position your hands so you can push the screen outward with your thumbs.
- Remove the front cover by gently pushing outward with your thumbs. Use your index fingers to pull back on the front cover.

## Step 7



- Remove cluster by pulling on the rubber backing.
- Clean, repair, and/or replace as necessary.

To reassemble your device, follow these instructions in reverse order.