



2010-Present Subaru Legacy Disconnecting Battery

Use this guide to disconnect your battery!

Written By: Miroslav Djuric



INTRODUCTION

Disconnecting the battery is a great first step for any car repair that involves electronics.



TOOLS:

- [10mm Wrench](#) (1)
-

Step 1 — 2010-Present Subaru Legacy Disconnecting Battery



- Lift the hood of your Subaru so you can access the battery.
- Use a 10 mm hex wrench to loosen the black Ground terminal screw.
 - ❗ Remember: righty-tighty, lefty-loosey.
- Lift the terminal up and off the battery lead, taking care not to touch the Positive terminal.
- Move the ground terminal out of the way so that it has no chance of accidentally reconnecting, or touching the Positive terminal.

To reassemble your device, follow these instructions in reverse order.