





# BlackBerry 7100g Battery Housing / Speaker Replacement

Written By: Kellan



---

# INTRODUCTION

This guide shows you how to remove both the battery housing and the speaker.

---



## TOOLS:


- [Spudger](#) (1)
  - [T6 Torx Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery



- Turn over your BlackBerry 7100g so that the back cover is facing up.
- Locate the battery cover release button near the bottom of the back panel.


## Step 2



- Push down on the release button with one thumb.
- Slide the battery cover off with the other thumb.




### Step 3




- Remove the battery from the battery housing by flipping up the top of the battery.

### Step 4 — Housing



- Locate the silver strip near the top of your BlackBerry.
- Use a plastic opening tool to pry off the edge of the silver lining.
- Slide the tool along the length of the silver strip to completely remove it.

## Step 5



**i** Do not lose the screws. They are quite small and can easily be misplaced.

- Locate and unscrew the four (4) screws using a T6 screwdriver.

## Step 6



**i** The keypad cover may fall out of the housing when prying the housing apart.

- Tightly pinch the top of the front and back halves of the housing.
- Carefully pry the two halves of the housing apart.



## Step 7




- You can now easily remove the "guts" of the phone from the housing.

## Step 8 — Battery Housing / Speaker



- Turn over the motherboard so that the speaker is facing up.
- Locate and unscrew the four (4) screws near the bottom of the motherboard, using a T6 screwdriver.

## Step 9



- i** The battery terminal is separate from the battery housing.
- Do NOT get rid of the terminal if replacing the battery housing and/or the speaker.
  - The terminal will slide out of the housing.

To reassemble your device, follow these instructions in reverse order.