



Repairing Parrot Bebop Drone Bottom Parts

Use this guide to replace the lower assembly including: engines, cross, rubber pieces, feet, and antennas.

Written By: David Hoyt



INTRODUCTION

Use this guide to replace the lower assembly including: engines, cross, rubber pieces, feet, and antennas.

[video: http://youtu.be/_M3DZ7X-RCg]

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
 - [Precision Utility Knife](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
 - [T8 Torx Screwdriver](#) (1)
-

To reassemble your device, follow these instructions in reverse order.