



Canon PowerShot G12 Retaining Bar Replacement

Replace the Canon PowerShot G12 Retaining Bar

Written By: Alexandra Millett



INTRODUCTION

Replacing the retaining bar takes little effort. If the bar has become cracked or similarly broken, then it will need to be replaced.

In this guide, you will learn how to replace the retaining bar and quickly resume the use of your wrist strap.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Retaining Bar



- Hold the camera so the retaining bar is visible.

Step 2



- There is one screw on the left and right sides of the retaining bar. Using a Phillips-head #00, unscrew each.

Step 3



- Remove the current bar and insert its replacement.

To reassemble your device, follow these instructions in reverse order.