



# How to Change Broken Buttons on your Lexus Key Fob

Are the buttons on your Lexus key fob not...

Written By: Michael Tan



# INTRODUCTION

Are the buttons on your Lexus key fob not responding anymore? Use this guide to learn how to open the key fob and swap out the buttons. The only tool you will need to complete this repair is your key fob!

## Step 1 — Broken Buttons



- Place the key fob with the removable metal key facing towards you.

## Step 2



- With the button side facing you, pull the metal latch down towards you to pull out the key.

### Step 3



- With the exposed corner facing you, place the metal key into the slot.
  - Turn the key sideways to open the key fob.
- ⚠ You may feel like you're breaking the key fob, but be firm while twisting.

### Step 4



- Remove the motherboard and battery to access the buttons.

## Step 5



- Rotate the front plate, the broken buttons should fall out with ease.
  - Replace the broken buttons as necessary.
- 

To reassemble your device, follow these instructions in reverse order. Apply firm pressure when snapping the front and back covers together.