

iPod Nano 2nd Generation Bottom Bezel Replacement

Written By: iRobot



INTRODUCTION

The plastic part on the bottom of the iPod.



TOOLS:

• iFixit Opening Tools (1)



PARTS:

• iPod nano (2nd Gen) Bottom Bezel (1)

Step 1 — Bottom Bezel



i Before opening your iPod, ensure that the hold switch is in the locked position.

Step 2



- When removing the the bottom bezel, be sure not to bend the plastic surrounding the dock connector.
 - Carefully insert an iPod opening tool in the seam between the metal casing and white plastic bezel
 - Lift the bottom bezel off the iPod. It's glued on using a mild adhesive, so some force may be required.

To reassemble your device, follow these instructions in reverse order.