

Amazon Fire TV Remote Control Batteries Replacement

This guide will show users how to replace the batteries in the Amazon Fire remote control.

Written By: Alejandro Franco Ceron



INTRODUCTION

Is your remote control unresponsive? Try changing the batteries with this guide!

Step 1 — Batteries





- Turn the remote control over to show its back and place your index finger in the tab. Squeeze gently to open the battery cover.
- Lift the battery cover up to expose the batteries.

Step 2





Guide ID: 51203 - Draft: 2017-12-02

- Use your index finger to push the battery back and lift up to remove the battery.
- Repeat the procedure for the second battery.

To reassemble your device, follow these instructions in reverse order.