



Sony VAIO PCG-933A RAM Replacement

How to replace or add memory to your Sony VAIO...

Written By: Sara Lillard



INTRODUCTION

How to replace or add memory to your Sony VAIO PCG-933A laptop.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Turn the laptop upside down so that the top is sitting on a flat surface.
- If you are looking at the bottom of the laptop the battery is located on the front right side of the laptop; the opposite side from the floppy disk drive.

Step 2



- As shown by the arrow, slide the plastic cover up and then pull out and downwards.
- You should now be able to pull the battery out.

Step 3 — RAM



- With the laptop facing you, flip the laptop upside down.

Step 4



- Remove the 4mm Phillips screw that holds the small panel in the center of the laptop in place.
- Then remove the panel covering the RAM.
- The RAM should now be visible.

Step 5



- Release the plastic switches on each side of the stick of RAM.
- Carefully slide the stick of RAM out at an angle.

⚠ DO NOT FORCE OUT.

To reassemble your device, follow these instructions in reverse order.