

Kyocera Hydro Vibe Volume Button Replacement

This guide will show you how to replace the volume button on the Kyocera Hydro Vibe.

Written By: Juliane Vo



INTRODUCTION

Sometimes the volume button gets stuck and you need to replace it/ fix it. This guide will allow you to do that.

TOOLS:

- Metal Spudger (1)
- iFixit Opening Tools (1)
- Screwdriver (1)
- Precision Tweezers Set (1)

Step 1 — Battery



- (i) Make sure that the device is turned off before beginning.
- Look for a small indentation on the bottom of the phone.
- Insert the plastic opening tool into the indentation and lift off the back casing.

Step 2



- The large white component is the battery. Look for a small indentation under the arrow that says "LIFT."
- Place the plastic opening tool in the indentation and lift the battery out of the socket.

Step 3 — Trim



- Locate the screws holding the trim which are the four side screws on each corner.
- Remove each screw with a Phillips screw driver #J00. The screws are 5mm Phillips.

Step 4



- Locate the clasps holding the trim in place.
- You will need to insert the metal spudger through the bottom of the trim and slowly push upwards to release the clasps.

Step 5



The trim is flimsy.

• This is what the trim will look like once removed.

Step 6 — Volume Button



- Once you have taken out the trim, the volume button will be easily removable.
- Locate the volume button, if you are looking at the back of the phone (battery side) then it will be on the right side.
- Take the tweezers and remove the button.

To reassemble your device, follow these instructions in reverse order.