



# Kenwood KDC-BT362U Front Panel Replacement

This guide will demonstrate how to remove the front panel of the radio to access the internals of the device for repair.

Written By: Pablo Cabrera



---

## INTRODUCTION

This guide is a prerequisite to getting inside your device for repair. Before any internal parts are replaced, the front panel must be completely removed. This removal allows for access into the device's interior.

---

### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Front Panel



- Locate the face-plate eject button.

## Step 2



- Press the eject button with your forefinger.
- Remove the face-plate.

### Step 3



- Starting on the top side, pop the front panel frame out.
- Remove the face-plate frame.

### Step 4



- Use the plastic opening tool to pry open the tabs.
- Repeat on the opposite side.

## Step 5



- Remove the front panel.

To reassemble your device, follow these instructions in reverse order.