



Asus G73JH-RBBX05 Hard Drive Replacement

This guide will help you locate and remove the hard drive on your Asus G73JH-RBBX05.

Written By: Trevor Sprosty



INTRODUCTION

Locate and remove your hard drive for replacement or upgrade.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Hard Drive



- Flip the laptop over and remove the two 4mm screws located at the bottom of the laptop with the PH0 screwdriver.

Step 2



- Using a plastic opening tool or finger, remove the access panel.
- ⓘ Apply constant force until the panel releases from the clips underneath.

Step 3



- Locate the two, 4mm screws on the hard drive. Remove them with the PH0 screwdriver.

Step 4



- Using the black tab located on the hard drive, pull out the hard drive.

To reassemble your device, follow these instructions in reverse order.