



# Cuisinart Mini-Prep DLC-2A Case Disassembly

How to replace the back panel of the Cuisinart Mini-Prep Plus

Written By: Brendan Paxton



---

## INTRODUCTION

This guide will help you remove the back panel of the device to look inside the device.



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

## Step 1 — Cuisinart Mini-Prep DLC-2A Case Disassembly



- Remove the back panel using a Phillips #1 Screwdriver on the four screws that hold it in place.

To reassemble your device, follow these instructions in reverse order.