


HTC Evo 3D Vibrate Mechanism Replacement

This guide will help to replace the vibrating mechanism of the HTC Evo 3D. By completing this guide, your HTC Evo 3D will be able to use the vibration feature again.

Written By: James Burke



INTRODUCTION

This guide will show how one can disassemble and replace the vibrating mechanism of the HTC Evo 3D. Replacing this mechanism will help to restore the vibration feature to your phone.



TOOLS:

- Tweezers (1)
- iFixit Opening Tools (1)
- T5 Torx Screwdriver (1)
- Phillips #000 Screwdriver (1)

Step 1 — Vibrate Mechanism







Remove the outer casing of the phone with your hands by prying and lifting at the latch.

Step 2





• Remove the battery with your hands, lifting at the marked area.

Step 3



- Remove the SD card
- Remove the four T5 screws using the corresponding screwdriver.
- Remove the two J000 screws using the corresponding screwdriver.

Step 4







- With the battery removed, the inner case of the phone can now be removed.
- Using the plastic opening tool, pry the inner case off at the marked area. Continue prying around the entire perimeter of the phone.
 - This will remove the inner case, and allow access into the inner portion of the phone.

Be careful not rip or damage the ribbons inside this shell.

Step 5







- The vibrating mechanism is located on the motherboard, on the right.
 - The marked part is the vibrating mechanism.
- To remove the vibrating mechanism, use the tweezers to securely hold the wire and tug on it.
- The vibrating unit can then be disconnected from the motherboard using the tweezers, grasping the white part.

To reassemble your device, follow these instructions in reverse order.