

# PANASONIC NR B 53 V1 Refrigerator Water Filter hosing to Extern

Change the Water Filter to cheaper extern Device.

Written By: Schwarzstein



This document was generated on 2020-11-23 02:58:10 PM (MST).

#### **INTRODUCTION**

Water Filter have to be replaced every 6 months. The original Water Filter is expensive. So I decided to short the Filter and placed a cheap Filter outside.



# **TOOLS:**

- Phillips #2 Screwdriver (1)
- PLastictool or Woodpiece (1)
- Cutter for Waterhose (1)



#### **PARTS:**

- Waterhose 6,35 mm (1)
- Adapetr plugs (1)

## Step 1 — PANASONIC NR B 53 V1 Refrigerator Water Filter hosing to Extern







BEFORE DEINSTALLING THE FILTER CUT OFF THE WATER LINE. Lay a Towel in the Fridge.
 Also cut off AC Mains. This is an opened Waterfilter. Inside is a sort of coal which adsorbs unhealthy particles. It has to be changed every 6 months or less.

### Step 2



First take out three drawers. The Meat drawer is top, the Vitaminsafe is in the middle and the Freshzone is lowest. Between Meat & Vitaminsafe is a Bottom which is snaped in with clipse. Use a plastictool or a woodpiece to open the clips and remove the bottom. There are no screws.





 Behind the lowest drawer is an plastic panel, which can easy be pulled off. Now you can see the Water-reservoir for the Water Outlet. Also you can see on the right the hosing for the Waterfilter. There are no screws.







- The Botton above the lowest drawer has a heating foil. Unscrew on the back a PH2 Head screw. Also is a PH2 in front left at the Filter's place. Now carefully lift the Bottom. Take out the Styroporfoam-Element. Then open the Plasticbag which contains the Connector for the Heating. You should cut-off the AC-Mains before unplugging this Connector.
- Now you can remove the Heating; Top of the Bottom.
- Open the shorter PH2 Screw to release the LED-Light on the Bottom. That's necessary because
  with the wires at it you could not pull out the chassis of the Bottom.
- Now you can pull out the Chassis of the lower Bottom, use a Plastictool for the Clipse. Pull off the holder of the Waterfilter.







- Here you have the a picture of the Filterholder. The Towel soaks the water
- The Inputhose has 8 mm. The Output has 6,35 mm (1/4"). Lay a small Towel under the Holder.
- Pull off the hoses. Some Water could come out. Mark the tubes with red and blue tape. So it will be
  easier to reasemle if a warrranty-check could occur.

#### Step 6







Now you need some plug couplings. Adapter from 6,35 mm (thats 1/4 inch) to 8 mm (thats 5/16 inch), Coupling 6,35 to 6,35 and a piece of hose 6,35. Carefully cut the hose nice and clean with a ahrsp cutter. Now easy click these parts together. Now you have a Bypass for the original Filtermount.:)



 Here is a detail picture of the inlet and the outlet.





- Now put it all together, don't forget the PH2 Screws and you are done.
- Now you can mount an extren Waterfilter.
- The first water will be black from the coal. Don't drink it. Also there is now a lots of air in the hose, so the water will flow unregular and cause problems and weird sounds. Give it some time, the problems will solve. :)



- This is an Saw-Cut off the external Filter i've bought. You see the same adsorbing coal like in an original Filter.
- It costs about 10 Bucks. The
   Original costs about 80 Bucks. Two
   Filters are needed every year. So
   this was a good Decision. Enjoy
   your clean Water. :)
- Sorry for my bad english writing. I hope the pictures may help someone.

To reassemble your device, follow these instructions in reverse order.